

INSTALLATION POWER PLANT, PT-17, N2S-4




Figure 41

Index

No.	Part No.	Description	Cond.
1	A75N1-2832	Exhaust collector ring assy	N-S
	A75N1-2832-2	Pipe-exhaust cylinder #5	N-S
	A75N1-2832-4	Sleeve assy-exhaust pipe cylinder #5	N-S
	A75N1-2832-8	Tail pipe-exhaust cylinder #6	N-S
	A75N1-2832-13	Sleeve assy-exhaust pipe cylinder #6	N-S
	A75N1-2832-15	Pipe-exhaust cylinder #7	N-S
	A75N1-2832-17	Sleeve assy-exhaust cylinder #7	N-S
	A75N1-2832-19	Pipe-exhaust cylinder #1	N-S
	A75N1-2832-21	Sleeve assy-exhaust pipe cylinder #1	N-S
	A75N1-2832-23	Pipe-exhaust cylinders #2 & #3	N-S
	A75N1-2832-27	Pipe-exhaust cylinder #4	N-S
2	AG75-3168-1	Primer line-primer to strainer	FAA-PMA
3	401-1A	Primer-engine, original Stearman	Recond.
4	A75N1-2809	Starter crank extension assy	N-S
		Magnetos-ref. only. Ask for our engine accessories price catalog	

INSTALLATION POWER PLANT, PT-17, N2S-4 continued

Figure 41

Index

No.	Part No.	Description	Cond.
6	75-2842	Handle-starter trip	N-S
7		Tachometer drive shaft, ref. only - see instrument installation	
8	AC882-16-72	Hose-oil, ref only, see oil installation PT-17, N2S-4	
9	A75N1-3005	Line-oil tank vent, see oil installation PT-17, N2S-4	
10	75-2877	Scoop assy-cold air intake (fireproof fiberglass)	N-P
10	75-2877-1	Scoop assy-cold air intake less AG75-2876 screen	N-P
11	75-3018	Support assy-oil tank lh, ref. only see oil tank & line installation PT-17, N2S-4	
12	AG75-3028	Oil tank assy, ref. only see oil tank & line installation, PT-17, N2S-4	FAA-PMA
13	AGE75N1-3013-2C	Oil cap-light type, ref. only see oil tank & line installation PT-17, N2S-4	FAA-PMA
13	E75N1-3013-2	Oil cap-spring loaded type, ref. only see oil tank & line installation PT-17, N2S-4	
14	A-7	Ignition switch-original Stearman, ref. only see ignition switch installation	
14	A-9	Ignition switch-subst. on-off, l & r battery, ref. only see ignition switch installation	
15	5122	Horn-carburetor air (Continental)	N-S
16	A75N1-2900	Installation engine control, ref. only see engine control installation	
17	A75N1-2806	Duct assy-carburetor hot air intake	N-S
18	AG75-3168-2	Primer line-primer to carburetor	FAA-PMA
19	A75N1-2801	Air box assy-carburetor air control	Recond.
20	AGA75N1-3003	Oil line-drain valve to engine, ref. only see oil line installation PT-17, N2S-4	
21	AG75-3869	Oil line-oil pres. coupling to engine. Ref only, see instrument installation	
22	C-2A	Fuel strainer assy	N-S
23	75-3137	Channel-C2A strainer support	N-S
24	A75N1-3002	Line assy-thermowell oil inlet	N-S
25	A75N1-3009-1,-2,-3	Lines-oil, engine breather, ref. only see oil line installation PT-17, N2S-4	
26	AGA75N1-3102	Line-fuel, fuel valve to strainer, ref. only see fuel line installation PT-17, N2S-4	
27	75-3018-1	Support assy-oil tank rh, ref. only, see oil tank & line installation	
28	B-11	Starter-ref. only, see our engine accessories price list	
29	37D6114-4	Oil "Y" drain-Stock Stearman, ref. only see oil line installation, PT-17, N2S-4	
30	AGA75N1-3001	Line-oil drain, ref. only see oil line installation PT-17, N2S-4	