


INSTRUMENT LOCATIONS FOR PT-17, N2S-1, N2S-4, PT-13A & B



① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ③ ⑩ ⑪

<u>Index No.</u>		<u>Index No.</u>	
4	Altimeter	8	Compass
5	Airspeed	9	Engine Gauge Unit
6	Clock	10	Tachometer

INSTRUMENT LOCATIONS, N2S-3

<u>Index No.</u>	
3	Airspeed
4	Turn & Bank
5	Compass
6	Engine Gauge Unit
7	Card Check List
12	Tachometer
16	Altimeter

